

NANO<sup>®</sup>CONNECT




USER MANUAL

# Smart Tag

---

NC-SMT01AFM

## 1. PRODUCT DIAGRAM



**1** Lanyard hole

**2** Sound holes

**3** Button


**4** Screw

## 2. ADD SMART TAG TO APPLE FIND MY

- (1) Make sure your iPhone has iOS 14.5 or later (iPad, iPadOS 14.5 or later). Turn on Bluetooth on your phone.
- (2) Press the button to turn on the power.
- (3) Open the Apple Find My app on your device.



(4) Click 'Add Item'



(5) Click 'Other Supported Item'



[6] Wait



[7] Connect



[8] Choose a name



[9] Choose an Emoji



[10] Wait for




[11] Tag is linked

### 3. FIND ITEMS AT CLOSE RANGE - PLAY SOUND FUNCTION

You can click 'Play Sound' in the Find My app, or say "Hey Siri, find my keys" to make the device emit a sound, helping you locate it easily. If it's nearby, like under a cupboard or in the next room, you can easily follow the sound to find it.

Additionally, you can click on 'Route' in the Find My app to get directions and locate your tag using the route.




## 4. BATTERY REPLACEMENT



[1] Loosen the screws

[2] Open back of the Smart Tag



[4] Put back cover back in place

[3] Replace battery



[5] Tighten screws



Check screws don't fall out of the cover

## 5. SPECIFICATIONS

Model:	NC-SMT01AFM
Bluetooth Version:	V5.2
Battery Type:	Button cell CR2032 (Replaceable)
App:	Apple Find My
Size:	41x32x8.2mm
Weight:	9.1g

## 6. PACKAGE CONTENTS:

Smart Tag  
Stainless steel rope loop  
CR2032 Lithium Battery  
User Manual

## 7. BLUETOOTH CONNECTION

If the distance between the paired Smart Tag and the iOS device exceeds the Bluetooth connection distance (20m in a closed, barrier-free space), clicking "Play Sound" in Find My app will mean the connection cannot be made. However, if Smart Tag and the iOS device are within Bluetooth connection distance, clicking "Play Sound" in Find My app will make Smart Tag emit consecutive sounds, enabling you to easily find items by following the sound.

## **8. FIND ITEMS WITH HELP FROM MILLIONS OF FRIENDS**

The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac or the Find Items app on Apple Watch.

Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple or the maker of your personal item, can view its location.

## **9. LOST MODE - FIND THINGS EASIER**

The Smart Tag can be put into Lost Mode. You will automatically receive a notification when its detected by other devices in the Find My network. To activate Lost Mode, open the Find My app and follow the onscreen instructions, where you can add your phone number or email account. This way, if someone else picks up your Smart Tag, they can easily contact you by following the instructions in Find My.



## **10. UNWANTED TRACKING PROTECTION**

To protect against unwanted tracking, if someone else's tracking device is detected with you for a period of time, your Apple device will find it and send you an alert notification. If you haven't found this device after a while, it will play a sound to help you locate it. However, if someone next to you has a tracking device and it's near its owner, you will not receive a notification.

## **11. PRIVACY PROTECTION**

Only you can see where your Smart Tag is located. No location data or location history is physically stored inside the tag. Communication with the Find My network is end-to-end encrypted, ensuring that only the device owner has access to its location data, and no one, including Apple and Smart Tag manufacturer, knows the identity or location of any device that helped find it.

## **12. ENABLING**

### **'NOTIFY WHEN LEFT BEHIND'**

Open Find My app and select the 'Items' tab or open the Find Items app on your Apple Watch.

Tap on your Smart Tag from the list. Under 'Notifications' enable the 'Notify When Left Behind' toggle.

You will receive a notification when you leave your Smart Tag behind and it's no longer in range of your device.

## 13. ENABLING

### 'NOTIFY WHEN FOUND'

Under 'Notifications' enable the 'Notify When Found' toggle. When your Smart Tag is seen by another Find My network device, you'll receive a notification of its location. **Note:** 'Notify When Found' can only be activated when your Smart Tag is out of range.

## 14. REMOVE THE SMART TAG FROM FIND MY APP

Open Find My app and select the 'Items' tab. Tap on your Smart Tag from the list. Please ensure 'Lost Mode' is disabled. Scroll to the bottom of the screen and tap 'Remove Item'. A summary will open, tap 'Remove' to confirm.

## 15. TURN OFF AND FACTORY RESET YOUR SMART TAG

1. Long press to turn off
2. For reset, first remove the Smart Tag from Find My app, then short press the tag's button four times, and long press on the fifth time. If you hear a different 'on' sound, the reset is successful. Smart Tag is now reset and can be paired with your new Apple ID.


## 16. PRODUCT SIZE

The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac or the Find Items app on Apple Watch.

To use the Apple Find My app to locate this Smart Tag, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.





Works with

Apple Find My



THIS PRODUCT CONTAINS BUTTON CELL BATTERIES. SCAN THE QR CODE FOR MORE INFORMATION.

**WARNING:** BUTTON CELL BATTERIES ARE HAZARDOUS (NEW OR USED). KEEP AWAY FROM CHILDREN. BUTTON CELL BATTERIES CAN CAUSE SEVERE OR FATAL INJURIES IN 2 HOURS OR LESS IF THEY ARE SWALLOWED OR PLACED INSIDE ANY PART OF THE BODY. IF YOU SUSPECT YOUR CHILD HAS SWALLOWED OR INSERTED A BUTTON CELL BATTERY, CALL THE 24 HOUR POISONS INFORMATION CENTRE IN AUSTRALIA ON 131126 OR IN NEW ZEALAND ON 0800 764 766 OR CONTACT YOUR COUNTRY'S EMERGENCY DEPT. USED BATTERIES MUST BE DISPOSED OF IN THE GARBAGE OR A BATTERY RECYCLING FACILITY.

### WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as 2 hours.
- **KEEP** new and used batteries **OUT OF REACH** of CHILDREN
- Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.

